

## **Product Change Notification**

Quality/Reliability

This document is the property of e2v semiconductors, not to be disclosed or copied without prior written consent

Printed form FC32S00970 / Rev L

Product Change Notification Number: GC170751 Date: February 16<sup>th</sup>, 2017

Title: PC8640 migration to lead-free bumps


Product Identification: all PC(X)8640\_\_GH\_\_ references, PC8640DFGH1000HE PC8640DVGH1067KE PC8640MGH1250HEZB6 PC8640DFGH1000HEM3 PC8640DVGH1067NE PC8640VGH1250HC PC8640DFGH1067NC PC8640DVGH1250HE PC8640VGH1250HE PCX8640FGH1067NCG PC8640DFGH1067NE PC8640FGH1067NE PC8640DFGH1067NE PC8640FGH1067NEG5 PC8640DMGH1250HE PC8640MGH1250HE **Reason for Change:** Processing Logistics Design

## **Change Description:**

Other

NXP has announced (\*) the replacement of the leaded C4 bumps by Lead free C4 bumps on the 8640 product family. Only bumps (die-to-package) change, solder balls (package-to-board) remain unchanged.

Manufacturing Location



(\*) Reference NXP Quality - 201701040DN - Discontinuation Notification February 03<sup>rd</sup> 2017.

## **Identification Method to Distinguish Change:**

The product change will be identified by a specific package code to distinguish the die bump metallurgy options. "GH" string will be replaced by "JH". For example PC8640DFGH1067NE becomes PC8640DFJH1067NE.



## Product Change Notification

|  | This document is the   | e property of e2v semiconductors, not to be dis                              | sclosed or copied without prior written consent                               |
|--|--|--|---|
| Qualification Data for the JH  | available  | n:<br>⊠ will be available<br>lanuary 2018                                    | ☐ not applicable  |
| "JH" unqualified samples: PCX8640JH  | available  |  | not applicable  |
| "JH" qualified samples:<br>PC8640JH  | available  |  | not applicable  |
| Quantifiable Impact on Qua<br>This change does not affect the<br>unchanged. The C4 bumps co<br>of all other materials used in this<br>impact on reliability is expected.       | fit, form, function<br>imposition is the<br>s product remain | ons of the part and the electri<br>e only material affected by thi           | s change. The composition   |
| Implementation Date**: Last orders to e2v for the GH pare e2v shipments shall be no later  | •  |  | to comply with NXP deadline.  |
| Lead-time shall be confirmed a lead-time will be definitively com  | •  |  |   |
| **The Estimated Implementation Date is the estimated date of inventory depletion on talthough customers should be prepared to until a time in which inventory has been didate. | he PCN issue date.<br>receive changed pro                    | This may be affected by fluctuations duct on this date, e2v semiconductors w | in supply and demand. Consequently, vill continue to ship pre-changed product |
| e2v semiconductors contact:  |  |  |   |
|  | Quality  |  | arketing  |
|  | TOURNIER<br>TLINE-STD@e2v.coi                                | L.GIRY<br>m semicondo  | uctors.MKT@e2v.com  |
| Would you need further inform product availability requirements  |  |  |   |
| APPROVAL by TRB  |  |  |   |
| e2v semiconductors will deem this chadays from the date of this notice. All co   |  |  |   |

e2v semiconductors assumes no responsibility for any errors that may appear in this document.

The supply of products will be subject to e2v general terms and conditions of sale or any specific contractual terms agreed between the parties.

The collect of contact and email addresses is key for e2v. e2v must keep informed its customers from its production evolution from introduction to change ( PCN ) up to phasing out ( Discontinuation Notice and EoL). Do not hesitate to provide to us any central or desk email address you feel important to secure the wide diffusion of such information.

For a list of available PCN and EOL announcements, please consult our web site :

http://www.e2v.com/products/semiconductors/obsolescence-planning-slim/